






## Step 12






















# BZ5-KIT BZ5 Belt Drive 4WD Chassis Instruction CM 1.4 x 4 CM 1.4 x 4 Step 27 PM 1.6 x 4 KM 1.6 x 4 PM 1.6 x 4 Step 28 Tighten Loosen oosen Tighter For Rear belt, recommend adjusting as 1 click loosen (toward to center of car) For front belt, recommend adjusting as 1 click **Belt Tension Adjustment** loosen (toward to center of car)


















**Motor Installation Note** 





BZ5 Gear Ratio	<u>51 Spur</u>	<u>52 Spur</u>	<u>53 Spur</u>
16	5.36	5.46	5.57
17	5.04	5.14	5.24
18	4.76	4.85	4.95
19	4.51	4.60	4.69
20	4.28	4.37	4.45
21	4.08	4.16	4.24
22	3.89	3.97	4.05

### Motor KV and suggested Gear Ratio

2500KV : 4.0 to 4.1 3500KV : 4.3 to 4.4 4500KV : 4.5 to 4.6 5500KV : 4.7 to 4.9

6500KV : 4.9 to 5.2